

# HYUNDAI Coupé 2,0l (10/2005), 8252-458

### *Assignments of the Fuses*

ROOM LP  
10A

IG COIL  
20A

A M P  
20A

B/UP LAMP  
10A

A/BAG IND  
10A

A/BAG  
15A

HTD MIR  
10A

HAZARD  
10A

R/WIPER  
15A

TAIL-RH  
10A

F/WIPER  
20A

SPARE FUSE  
10A

RR DEFOG  
30A

STOP  
15A

TAIL-LH  
10A

A/CON  
10A

E C U  
10A

CLUSTER  
10A

P/WINDOW  
30A

T/GATE  
15A

I G N  
10A

RR FOG  
10A

C/LIGHT  
15A

S/ROOF  
15A

S/HTR  
20A

A B S  
10A

AUDIO  
10A

SPARE FUSE

SPARE FUSE

SPARE FUSE

SPARE FUSE

USE THE DESIGNATED FUSE ONLY.

(blanc)  
20A - Ignition coil (2,7l), Electronic chrome mirror  
20A - AMP  
10A - Backup lamp switch, Transaxle range switch, Cruise control module, Cluster R position  
10A - Instrument cluster (A/BAG IND.)  
15A - SRS control module, S/Buckle DRV, ASS

10A - Mirror defrogger  
10A - Hazard relay  
15A - Rear wiper motor, Rear intermitten wiper relay  
10A - Right tail lamp, Glove box lamp, Room lamp, C/Light tail  
20A - Front wiper motor, Front wiper relay  
10A - Spare Fuse

30A - Defogger relay  
15A - Stop lamp switch, Burglar alarm horn relay, Folding/Unfolding relay, TPMS  
10A - Left tail lamp  
10A - A/C control module, Blower relay, Sun roof, Ambieut Display  
10A - ECM, Multi gauge unit, TCM, Vehicle speed Sensor, TPMS  
10A - Instrument cluster (Power), Per-excitation resistor, DRL Control module, Generator

15A - Trunk lid switch  
10A - AQS sensor,Head lamp relay, DRL control module  
10A - Rear fog lamp  
15A - Cigarette lighter, Outside mirror switch

10A - Room lamp, Clock, Audio, Data link connector, Multi gauge unit, Cluster, A/Con  
30A - Poser window relay

15A - Sunroof, Power door lock/unlock relay  
20A - Seat warmer  
10A - ESC/ABS control module  
10A - Audio, Digital clock

Spare fuses (10A, 15A, 20A, 30A)